

# Rotary Vane Vacuum Pumps TRIVAC B

A proven concept



### **TRIVAC B**

### Dual stage rotary vane vacuum pumps

Oil sealed rotary vane vacuum pumps are used in all areas of vacuum technology and are particularly well-suited to many applications in production and research.

These pumps are used to pump down to pressures in the rough or medium vacuum range, or as backing pumps in combination with roots, diffusion, turbomolecular or cryopumps.



### **Special features**

TRIVAC B series pumps are oil sealed vacuum pumps based on the rotary vane principle.

The oil injected into the pump chamber is used for sealing, lubrication and cooling purposes. The inner pump body is made of separate components with no additional sealing elements. The components are fitted with dowels to ensure easy disassembly and re-assembly.

#### **Environment-friendly**

- Low noise
- Low vibration

#### **Energy saving**

- Low power consumption
- Low thermal losses

#### Modern vacuum technology

- High pumping speed right down to the ultimate pressure
- Low ultimate pressure, even with gas ballast
- High water vapor tolerance
- Continuous operation right up to 1000 mbar
- Built-in oil pump, force-feed lubrication sliding bearing
- Minimal inherent air intake
- Highly leaktight (<sup>4</sup>He-capable)

#### Well-proven design

- Compact, air cooled
- Handy, retractable handle
- All controls and oil level check on the front side
- Either horizontal or vertical intake and exhaust port
- Service-friendly
- Exchangeable inner section
- Installation of mechanical and chemical/mechanical full flow oil filters possible
- Shaft seals and O-rings are all made of elastomer FPM
- Pumps are free of non-ferrous metals
- Motor protection IP 54/IP 55



### **TRIVAC B**

# For vacuum work in industry and research





# **Applications**

	•
Production of semiconductors	
Vacuum coating	
Research and development	
Chemistry/pharmaceuticals	
Metallurgy/furnaces ■ ■	
Lamps and tubes manufacture	
Automotive industry	
Space simulation	
Analytical engineering	
Environment engineering	
Cooling and air-conditioning	
Electrical engineering	
Mechanical engineering	
Medicine technology ■ ■ ■ ■	
Vacuum drying cabinets ■ ■ ■ ■	
Chemistry and research labs	
Freeze-drying systems	
Backing pump for   high vacuum pump systems   ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	
Leak detectors	

<sup>\*</sup> Please refer to our full line catalog for the complete range of TRIVAC pump models and applications

### TRIVAC B / BCS

### Technology you can rely on





### **Design features**

#### **Coupling and motor**

The pumping section of the TRIVAC B is directly linked to the motor via an elastic coupling element to ensure that the pump runs evenly and smoothly. Type B 14 flanged motors are screwed to the housing of the coupling.

#### Gas ballast valve

The gas ballast valve is opened and closed by means of a short lever. By admitting a well controlled amount of air - the gas ballast - it is possible to prevent a certain degree of vapor condensation within the pump.

#### **Exchangeable inner section**

The inner section of the pump may be exchanged without special tools or any special knowledge. It consists of all components vital to the operation of the pump. Exchanging the inner section makes the TRIVAC B as good as new again.

#### 1000 mbar intake pressure

Trouble-free operation even at 1000 mbar intake pressure is ensured by a built-in oil pump, providing force-feed lubrication of the bearings from where a minimum amount of lubricant is fed to the compression and expansion chambers to ensure lubrication of the sliding vanes.

#### **Surface corrosion**

All components are protected against surface corrosion. Non-ferrous metals are not used. The oil box, intake and exhaust line are made of aluminum and only solvent-resistant sealing materials are employed.

#### **Flexible**

All pumps from the D 4 B to the D 25 B are available with either a single-phase or a three-phase AC motor. Other pumps and motors are available upon request.

#### **Anti-suckback valve**

An oil pressure-controlled anti-suck-back valve is built into the intake of the TRIVAC B. During stand-still (as a result of a power failure, for example), the anti-suckback valve blocks the intake to prevent a pressure rise in the connected vacuum system. At the same time, the inner pump body of the TRIVAC is vented. The blocking process will also work correctly when operating the pump with an opened gas ballast valve.

As a result, the backstreaming of any oil from the pump into the vacuum system is effectively prevented. The leak rate of the anti-suckback valve is less than 3 x 10<sup>-5</sup> mbar/ls<sup>-1</sup>.

#### TRIVAC BCS

The fields of operation for TRIVAC BCS models will be found wherever an increased tightness, numerous accessories and/or monitoring capabilities are required.



### Complete product range



### **Accessories**

TRIVAC models*	D4B	D8B	D16B	D25B	D40B	D65B	D16B ex	D16 BCS D25 BCS D40 BCS D65 BCS
Exhaust filters AF(-DOT)								
Condensate traps / separators AK					_			
Exhaust filters with								
lubricant return ARP / AR lubricant return ARS								
Oil drain tap								
Oil drain kit								
Dust filters FH/DF, DN 16 - 40 ISO-K	F							
Adsorption trap FH/RF, DN 16 to 40 ISO-KF						п		
Cold trap TK								
Dust separators AS								
Molecular filters MF								
Mechanical oil filters OF								
Chemical oil filters CF								
Chemical filters with safety isolation valve CFS								
Inert gas system IGS								
Limit switch system LSS								
Roots pump adapter								
Flange components, valves								

<sup>\*</sup> Please refer to our full line catalog for the complete range of TRIVAC pump models and accessories

#### Oil filters OF/CF

Since there is a pressure-lubrication system with an oil pump in every TRIVAC B, it is possible to connect main flow oil filters. These filters are available either for mechanical filtering (OF types) or combined chemical/mechanical filtering (CF types).

#### **Advantages:**

- Enhanced life span of the pumps
- Extended oil service life (application-dependent)
- Easy installation on the TRIVAC B
- No hose connections required
- Easily exchangeable filters
- Low oil loss during filter exchange
- Expanded range of applications to meet special requirements
- Prevents mechanical pump damage
- Identical filter housings
- Maintenance indicator for exceptional reliability

#### **Condensate traps AK**

Condensate traps protect the pumps against the accumulation of condensate and backstreaming of fluids.

#### **Advantages:**

- Easy installation without the use of additional accessories
- For use either on the intake or exhaust side
- Solvent-resistant
- Drain via drain screw or drain tap

Under certain circumstances liquid may accumulate in the intake line when pumping vapors. In such cases, it is advisable to install a condensate trap on the intake side of the TRIVAC B. Its use is also recommended in situations where it is awkward to run the exhaust line and where the exhaust line may drain back to the pump.

#### Roots pump adapter

The Roots pump adapter allows the direct installation of a small Roots pump on a TRIVAC D40/65B/BCS.

#### **Advantages:**

- Compact and space-saving
- Short and direct connection between the pumps
- Low conductance loss
- Easy installation



TRIVAC D 16 B with translucent plastic exhaust filter AF and condensate trap AK



#### **Exhaust filters AF**

These exhaust filters retain oil mists, aerosols and harmful substances.

#### **Advantages:**

- Retains dirt and cracked products
- Built-in overpressure relief valve
- Separation efficiency over 99%
- Sight glass for checking the quantity of collected substances
- Exchangeable filter inserts
- Solvent-resistant
- Easy to use and to clean

#### Exhaust filters with lubricant return ARP/AR/S

This combination of an exhaust filter and a float-controlled valve considerably extends the maintenance intervals of the TRIVAC B. As a result, oil consumption is lowered to negligible levels.

#### Advantages:

- Filtering the exhaust air of entrained lubricant particles
- Lubricant return with the aid of a float-controlled valve
- No operation costs caused by lost lubricant
- Standard filter element
- Built-in overpressure relief valve
- Hardly any oil consumption
- All seals made of FPM (FKM)
- The intake port may be easily exchanged (either vertical or horizontal orientation)

Exhaust filters with lubricant return are connected to the exhaust port of the TRIVAC B while the return line is connected to the intermediate flange under the intake line.

Depending on the properties of the pumped medium, we recommend connecting an exhaust line to the exhaust filter - particularly when pumping hazardous substances.



Dust filter casing (empty), for optional equipping



Adsorption traps and filter insert with various adsorbents



Application example

#### **Dust filters**

Dust filters protect the pump against inlet particles. They consist of a steel casing with a cover featuring three locking clips for fast and easy opening and closing. The dust filter casings are equipped with a ISO-KF flange.

The filter housing are supplied without inserts. The filter insert should be selected for the individual requirements.

#### **Advantages:**

- Easy to fit
- Vacuum tight steel casing
- Easy filter replacement
- High filter capacity

#### **Adsorption traps**

The adsorption traps are containers with a stainless steel insert which can be filled with different kinds of adsorbents. They provide a high adsorbing capacity for vapors and water vapor in particular.

#### **Advantages:**

- Stainless steel adsorption inserts (option)
- Bakeable stainless steel insert (up to 300 °C) for adsorbent regeneration
- For use with various adsorbents and separating components
- Simple and rapid replacement of insert and adsorbent
- Cost-effective generation of hydrocarbon-free vacuum
- Low maintenance costs compared to many dry compressing pumps

### **Technical data**

# Ordering information

TRIVAC B		D 4 B	D 8 B	D 16 B	D 25 B	D 40 B	D 65 B
Nominal pumping speed 1)	m³/h	4.8	9.7	18.9	29.5	46.0	75.0
Pumping speed 1)	m³/h	4.2	8.5	16.5	25.7	40.0	65.0
Ultimate partial pressure 1) without gas ballast	mbar	< 1 · 10-4	< 1 · 10-4	< 1 · 10-4	< 1 · 10-4	< 1 · 10-4	< 1 · 10-4
Ultimate total pressure 1) with gas ballast	mbar	< 5 · 10 <sup>-3</sup>	< 5 · 10 <sup>-3</sup>	< 5 · 10-3	< 5 · 10 <sup>-3</sup>	< 5 · 10-3	< 5 · 10-3
Water vapor tolerance	g/h	95	160	305	480	1185	1925
Oil filling min./max.	1	0.3 / 0.8	0.3 / 0.9	0.45 / 1	0.6 / 1.4	1.7 / 2.6	2.0 / 3.3
Motor power	W	370	370	550 / 750	750	2200	2200
Rotational speed of the pump	U/min.	1500 (50 Hz) / 1800 (60 Hz)					
Connection ports	DN	16 ISO-KF	16 ISO-KF	25 ISO-KF	25 ISO-KF	40 ISO-KF	40 ISO-KF
Weight	kg	17.9	18.9	31.5	35.8	72.5	81.7

<sup>&</sup>lt;sup>1)</sup> according to ISO/R 1000, DIN 28 400, and other German and international vacuum technology standards

Ordering information TRIVAC B rotary vane vacuum pur	nps, dual stage		D 4 B	D 8 B	D 16 B	D 25 B	D 40 B	D 65 B
with single phase motor		ATEX						
230 V, 50 Hz	Schuko	ATEX 3i	112 45	112 55	112 65	112 75	_	_
208-252 V, 50/60 Hz	Schuko **	ATEX 3i	_	_	113 25	113 35	_	_
110-115 V / 210-230 V, 50/60 Hz	Schuko **		140 081**	140 082**	_	_	_	_
110 V, 50 Hz/ 115 V, 60 Hz*	NEMA 5-15F	)	_	_	912 65-1	_	_	_
208-230 V, 50/60 Hz*	NEMA 5-15F	)	_	_	912 65-2	912 75-2	_	_
with three-phase motor		ATEX						
200-240 V, 50 Hz / 200-240 V, 60 Hz 200 V, 50 Hz (IE2) / 208-240 V, 60 Hz 380-400 V, 50 Hz / 380-400 V, 60 Hz 380-400 V, 50 Hz (IE2) / 416-480 V, 60	z (EPAct)	ATEX 3i	112 46	112 56	112 66	112 76	112 86	112 96
230 V / 400 V, 50 Hz		ATEX 3i/o	140 140	140 150	140 160	140 170	140 180	140 190
Accessories:								
Roots pump adapter			<u>-</u>		_		168 30	
Condensate trap			188 06 (AK 4-8) 190 60 (AK 8)		188 11 (AK 16-25) 190 63 (AK 16)		188 06 (AK 40-65)	
Exhaust filter			189 06 (AF 4-8) 190 50 (AF 8)		189 11 (AF 16-25) 190 53 (AF 16)		188 16 (AF 40-65)	
Exhaust filter with lubricant return			189 20 (AR 4-8)		189 21 (AR 16-25)		189 22 (AR 40-65)	
Dust filter and adsorption trap housing		140 116T (FH 16)		140 125T (FH 25)		140 140T (FH 40)		
Dust filter insert		140 117S (DF 16-25)				140 141S (DF 40-65)		
Adsorption trap filter insert, bakeable to 300 °C		140 118A (RF 16-25)				140 142A (DF 40-65		
Adsorbents			Active charcoal, zeolite, aluminum oxide, pa				e, pall rings	ations

Please refer to our full line catalog for the complete range of TRIVAC pump models and accessories.

The pumps and accessories described in this folder are a just a selection from our complete product range. Additional motors and oils upon request.



Leybold GmbH Bonner Str. 498  $\cdot$  D-50968 Köln

T +49 (0) 221-347-0 F +49 (0) 221-347-1250

www.leybold.com

info@leybold.com





M 09410\_12160-171.83.02 6.1.01.16 mzs din Germany on chlorine-free bleached paper